



## How to Care for Anchor Hocking Glassware

### How to Prevent Drinkware Breakage

1. Do not stack drinkware.
2. Do not put drinkware in the microwave.
3. Avoid picking up drinkware in bouquets.
4. Never put silverware into drinkware.
5. Avoid severe temperature changes.
6. Avoid impact.

### Glass Etching

Etching of glassware is a permanent film that cannot be removed; caused by the following:

1. Soft water, especially water that is produced by an installed water softening system.
2. High water temperature.
3. Too much dishwashing detergent.

The damage is permanent. There is no way to remove etching. If a dishwasher is used, the following steps can help to prevent reoccurrence:

1. Check for rainbow hue on glasses because that is the first sign of etching.
2. Reduce amount of dishwashing detergent; but, never use less than one tablespoon.
3. Put fewer dishes in the dishwasher to allow thorough rinsing.
4. Keep water temperature no higher than 140 degrees.

### How to Care for Your Bakeware

1. **HEAT IN OVEN ONLY.** Use your Anchor Hocking Bakeware in gas, electric or microwave ovens without browning element. Not for stovetop, broiler or toaster oven use. Do not use an alcohol or Canned Heat burner as a direct heat source.
2. **USE FOR STORING FOOD.** Use your Anchor Hocking Bakeware for storing food in refrigerator or freezer but do not take directly from freezer to oven. Let food thaw before cooking or reheating in oven.
3. **CLEAN WITH PLASTIC OR NYLON NON-SCRATCH PADS OR CLEANSERS.** Wash your Anchor Hocking bakeware in detergent and warm water. For stubborn baked on food, let the bakeware soak and then use non-scratch cleansers and scrub pads intended for glass

ovenware. Dishwasher safe.

4. **AVOID SEVERE TEMPERATURE CHANGES.** Do not add liquid to a hot dish. Handle hot bakeware dishes with a dry cloth or potholder. Never place hot bakeware on wet or cold surfaces.
5. **AVOID IMPACT WITH HARD OBJECTS.** Sharp knives or utensils may scratch and weaken glass bakeware. Do not use if chipped or cracked, or noticeably scratched.
6. **PLASTIC FOOD STORAGE COVERS** are designed for microwave ovens. Not intended for conventional oven, stovetop, broiler, or toaster oven use. Freezer, refrigerator & top rack dishwasher safe.
7. **BASKET** Accessories are designed for serving only. Fiber baskets are not for oven or microwave use.

### **How to Care for Your Pitcher**

1. Cold beverage use only. Do not use for hot beverages.
2. Avoid sudden temperature changes. Do not pour boiling liquid into this pitcher nor rinse it with hot water immediately after it has been used for cold beverages. Do not fill the pitcher with ice and then pour hot liquid over the ice.
3. Avoid impact with hard objects. Use plastic or wooden utensil when stirring liquid in the pitcher. Handle the pitcher with care and avoid striking it against other objects or surfaces. Do not use if chipped, cracked, or noticeably scratched.

# Anchor Hocking Bakeware 5-Year Warranty

- **OVEN AND MICROWAVE SAFE.** Use your Anchor Hocking bakeware in gas and electric ovens up to 425°F or microwave ovens without browning element. Not for stovetop, broiler or toaster oven use. Do not use an alcohol or canned heat burner as a direct heat source.
- **USE FOR STORING FOOD.** Use your Anchor Hocking Bakeware for storing food in refrigerator or freezer but **do not take directly from freezer to oven.** Let food thaw before cooking or reheating in oven.
- **CLEAN WITH PLASTIC OR NYLON NON-SCRATCH PADS OR CLEANSERS.** Wash your Anchor Hocking bakeware in detergent and water. For stubborn baked on food, let the bakeware soak and then use non-scratch cleansers and scrub pads intended for glass ovenware. Dishwasher safe.
- **AVOID SEVERE TEMPERATURE CHANGES.** Do not add liquid to a hot dish. Handle hot bakeware dishes with a dry cloth or potholder. Never place hot bakeware on wet or cold surfaces.
- **AVOID IMPACT WITH HARD OBJECTS.** Sharp knives or utensils may scratch and weaken glass bakeware. Do not use if chipped or cracked, or noticeably scratched.

PLASTIC FOOD STORAGE COVERS are designed for microwave ovens. Not intended for conventional oven, stovetop, broiler, or toaster oven use. Freezer, refrigerator & top rack dishwasher safe.

BASKET Accessories are designed for serving only. Fiber baskets are not for oven or microwave use.

## WARNING

Failure to follow these warnings may cause the product to suddenly fracture into many small pieces, which could result in property damage or serious personal injury from cuts or burns. Scratches from certain cleaning materials and utensils can weaken ovenware causing unexpected breakage when exposed to sudden temperature changes. Clean with on-scratch pads and cleaners intended for glass bakeware. Avoid severe temperature changes. Avoid impact with hard objects. Use only in ovens (conventional or microwave). Do not use or place on stovetop, under broiler or in toaster ovens.

## WARRANTY

Anchor Hocking Bakeware has a 5-Year Warranty. If it chips, cracks or breaks within 5 years from the date of purchase when used according to instructions, return the product with this warranty, along with a description of the claimed defect to the following address:

Anchor Hocking Company  
Consumer Affairs Department  
519 Pierce Avenue  
Lancaster, OH 43130, U.S.A.

Any implied warranties are excluded, or if not excludable under law, are limited to the same time period as the expressed warranty. Incidental and consequential damages are excluded. This warranty gives you specific rights and you may also have other rights, which vary from state to state.

# **Anchor Hocking Premium 10 Year Limited Warranty**

Premium bakeware is warranted to be free from defects in workmanship and material for ten (10) years from date of original purchase. If this product chips, cracks or breaks during this time period, return the product within the warranty period, along with a description of the claimed defect, to the following address:

Anchor Hocking Company  
Consumer Affairs Department  
519 Pierce Avenue  
Lancaster, Ohio 43130, U.S.A.

Any product found to have not complied with our warranty specifications will be replaced, at the warrantor's option.

ANY IMPLIED WARRANTIES ARE EXCLUDED, OR IF NOT EXCLUDABLE UNDER LAW, ARE LIMITED TO THE SAME TIME PERIOD AS THE EXPRESSED WARRANTY (Note: Some States do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you). INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED. (Note: Some States do not allow the exclusion of incidental and consequential damages so this limitation may not apply to you).

This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

## **WARNING**

Failure to follow these warnings may cause the product to suddenly fracture into many small pieces, which could result in property damage or serious personal injury from cuts or burns. Scratches from certain cleaning materials and utensils can weaken ovenware causing unexpected breakage when exposed to sudden temperature changes. Clean with non-scratch pads and cleaners intended for glass bakeware. Avoid severe temperature changes. Avoid impact with hard objects. Use only in ovens (conventional or microwave). Do not use or place on stovetop, under broiler or in toaster ovens.

## **CAUTION**

Comfort-Grip handles will get hot. Use oven mitts when handling. Comfort-Grip handles are safe for use in dishwasher, freezer, microwave and conventional oven up to 425 degrees F.

Heat in oven only. Use your Premium bakeware in gas, electric or microwave ovens without browning element. Not for stovetop, broiler or toaster oven use. Do not use an alcohol or Canned Heat burner as a direct heat source. Use your Premium bakeware for storing food in refrigerator or freezer, but do not take directly from freezer to oven. Let food thaw before cooking or reheating in oven. Clean with plastic or nylon non-scratch pads or cleaners. Wash your Premium bakeware in detergent and water. For stubborn baked on food, let the bakeware soak and then use non-scratch cleaners and scrub pads intended for glass bakeware. Avoid severe temperature changes. Do not add liquid to a hot dish. Handle hot ovenware dishes with a dry cloth or potholder. Never place hot bakeware on wet or cold surfaces. Avoid impact with hard objects. Sharp knives or utensils may scratch and weaken glass bakeware. Do not use if chipped or cracked, or noticeably scratched.