

Progressive®

Tower Slicer

At Progressive our goal is to make your busy life easier with innovative products for your kitchen. The Tower Slicer makes consistent slicing for snacks or garnishes quick and easy.

Features / Benefits

- Quickly and Easily Slices Fruits and Vegetables
- V-Shaped Blades Cut 11 Slices in One Swift Motion
- Non-Skid Feet

Pusher Lid
-Minimizes Hand Contact with Produce

Pusher Plate

Slicing Blade Insert

-V-Shaped

Base Container

-6 Cup (1.4 L) Capacity

Lid Cleaning Tool



To Use



1. Select blade insert and press into blade frame on base container.



2. Select pusher plate and align with blade insert.



3. Press pusher lid down to secure pusher plate on lid.



4. Lift pusher lid and check for correct positioning of parts.



5. Place food on blade insert. Soft and large foods should first be cut to size and placed on blades with the cut side down. For best results, press produce onto blades firmly to pierce skin before slicing.



6. Place both hands on pusher lid and press down quickly and firmly in one continuous motion. Ease of slicing may vary depending on freshness and size of fruit or vegetable. Repeat steps 5 and 6 as necessary. Periodically clean pusher plate with cleaning tool for best performance.



7. Lift/remove pusher lid and blade insert to remove cut produce.

Cleaning

- Use cleaning tool to remove food residue from pusher plate.
- Dishwasher safe.



Caution!

- Blades are very sharp! Use care when operating and washing item to avoid injury.
- Avoid using overly ripe produce in Slicer.