

VIATEK®


TOUCH 2 GO



made in china • revinstructco01/0906

Directions for Use

WARNING:
Disassembly of the electronic components within this unit may result in exposure to lead in the form of a solder, which is known to state of California to cause cancer, birth defects and other reproductive harm.



Installing the Batteries:

To remove the battery compartment cover press and slide down the bottom cover plate of the Touch 2 Go Hands Free Can Opener in the direction indicated by the arrow. Install two 'AA' batteries (not included) with the proper polarities aligned (+/-). Then replace the battery compartment cover.

Operation:

NOTE: Unit is not designed to work on oddly shaped cans.

Place the Touch 2 Go Hands Free Can Opener on the top of the can lid, with the front lip of the opener protruding over the edge of the can. Then press and hold the power button for approximately one second, this will allow the Opening Mechanism to adjust and grip the can's edge.

The Touch 2 Go Hands Free Can Opener slices the can under the rim eliminating sharp, dangerous edges and stops automatically at the end of the opening cycle. Once the cycle is complete the lid can be lifted off the can safely.

NOTE: The Touch 2 Go Hands Free Can Opener works on a timer, it may be necessary to start the cycle a second time when opening larger cans.

Maintenance:

In addition to replacing the batteries the Touch 2 Go cover plate can be removed for cleaning the cutting blade and other areas of the Hands Free Can Opener. The Touch 2 Go can be cleaned as any normal can opener.

If the Touch 2 Go gets jammed, use a thin object or your finger nail to push the reverse switch at the bottom end of the Touch 2 Go. This will force the can opener to reverse the direction of the opening mechanism and release the can. This may occur if the batteries are weak or the can is deformed.

If the above does not work the batteries could be totally exhausted, use a screw driver to manually turn the release knob clockwise on the front end of the Touch 2 Go to release the can. Then insert new batteries and begin the open cycle again.

