

6.6b./3 kg. DIGITAL ADD'N'WEIGH SCALE

DIRECTIONS FOR USE:

HOW TO INSTALL BATTERY:

- 1) Press and push open the battery cover located at the bottom of the unit.
- 2) Insert two CR2032 lithium size batteries flat side up, (+) polarity facing up and (-) polarity facing down.
- 3) Snap together and close battery cover until it clicks shut.

LOW BATTERY INDICATOR:

When the flashing battery symbol appears in the display, it means battery power is low. At this time you should replace the battery. When the battery is too low, it will show "----" and then it will turn off automatically.

TURN SCALE ON/OFF:

Place item on a flat surface before use.

- 1) Press "on/off/tare" button to turn scale on. A (0) will display after a few seconds and scale is ready to use.
- 2) Press and hold "on/off/tare" button for more than 3 seconds to turn scale off.

NOTE: AUTO SHUT OFF FEATURE WILL TURN SCALE OFF IF SCALE IS NOT IN USE FOR ABOUT 3 MINUTES.

TO SWITCH BETWEEN LBS. AND KGS.

- 1) Press "lb/kg" button once to choose kg. Press "lb/kg" button again to switch back to lbs.

Capacity: 6.6 lbs/3 Kg. - displays in 1gram/ 1/8 oz. increments.

HOW TO USE TARE FEATURE:

- 1) Place first item on scale, scale will display weight of the item.
- 2) Press "on/off/tare" button (less then 3 seconds). Display will revert to zero (0).

- 3) Place 2nd item on scale, scale will display weight of item.
- 4) Repeat steps 3 and 4 until all items have been weighed.

NOTE: There are two ways to set the scale at (0) when weighing items in a container.

- 1) Place the container on the scale before turning on the scale.
- 2) If the scale is already on, place the container on the scale and press the "on/off/tare" button which will zero out the scale.

NOTE: The scale will read "ERR" if weight on scale is above the scale capacity.

PRECAUTIONS:

1. Do not clean the unit with abrasive or corrosive compound. It may scratch the plastic and corrode the electronic circuit.
2. Do not overload the scale.
3. Do not subject the unit to excessive force, shock, dust, temperature, direct sunlight, heavy exposure to water or humidity, which may result in malfunction, shorter electronic life span, battery damage or distorted parts.
4. Do not tamper with the units internal components. It will invalidate the warranty.

ONE YEAR LIMITED WARRANTY

Polder will repair or at its option replace this product without charge, other than shipping charges, if it is returned to the address below with shipping charges prepaid, as being defective, within one year of the date of purchase and provided that inspection by the company indicates it is defective because of faulty workmanship or material. Please save your original receipt for this limited one year warranty to be valid. This limited warranty does not cover damage to this product through accident or misuse, nor does it cover any incidental expense to the user resulting from the non-function or malfunction of this product.