

One Year Limited Warranty

Taylor® warrants this product to be free from defects in material or workmanship for one (1) year from the original purchaser from date of original purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. If service is required, do not return to retailer. Should this product require service (or replacement at our option), please pack the item carefully and return it prepaid, along with store receipt showing the date of purchase and a note explaining reason for return to:

Taylor Precision Products
2220 Entrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA

There are no expressed warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Questions about this product:

If service is required, do not return to retailer. For service call 1-866-843-3905 from 7:30 am to 4:30 pm, Mountain Standard Time, Monday through Friday. To assist us in serving you, please have the model number and date of purchase available.

For additional product information, or warranty information in Canada or elsewhere outside the USA, please contact us through www.taylorusa.com.

Patent pending


©2009 Taylor Precision Products and its affiliated companies. All rights reserved. Taylor® and Leading the Way in Accuracy® are registered trademarks of Taylor Precision Products and its affiliated companies. All rights reserved.

Made to our exact specifications in China.
Not legal for trade
www.taylorusa.com

24

TAYLOR

3890

Digital Scale with Measuring Cup*Leading the Way in Accuracy®***Instruction Manual**

1

Thank you for purchasing a Taylor® Digital Scale with Measuring Cup. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

Please note: For an accurate reading for any type of kitchen scale, the scale must be resting on a hard, level surface. If this scale with measuring cup is held in the hand or is otherwise uneven, the buttons and digital display may not function properly.

Initial Setup And Battery Replacement**Initial Setup**


- This scale operates on one CR2032 Lithium battery (included).
- The battery is already installed. To activate, pull out the insulation strip from the battery door.
- After pulling the strip, rest the scale on a flat, even surface.
- Press the "0" button to turn the unit on. The display should read 0 (zero). Go to "Calibration" section to calibrate the scale if the reading is other than 0 (zero).

Battery replacement:

Your Taylor® scale is equipped with a low battery indicator. It will display a low battery icon or readings will grow dim or become irregular if the battery needs replacement.

Using a coin in the battery cover slot, rotate the battery door to the "OPEN" position. Remove the non-functioning battery. Replace with one CR2032 Lithium battery according to the polarity indicated. Again using a coin, rotate the battery door in reverse direction to the "CLOSE" position. Follow steps #3 & #4 above.

2

Description of Parts

Buttons	Single Press	Hold 3 Sec.	Hold 6 Sec.
0	Turn unit on Tare or reserve tare	Turn unit off	While unit is on, hold 6 seconds to calibrate/reset an empty cup, if needed
M (Mode)	Change Mode (Sugar/Flour/Scale/Water/Milk/Oil)		
U (Unit)	Select unit of measure (options vary by mode) (Sugar/Flour: Cups, Pounds/Ounces or Grams) (Scale: Pounds/Ounces or Grams) (Water/Milk/Oil: Cups, Fluid Ounces or Milliliters)		

Powering On/Off

- Place the cup on a flat, level surface and press the "0" button to turn on the unit. The display will flash "8888". The display should read 0 (zero). Go to "Calibration" section to calibrate the scale if the reading is other than 0 (zero).
- To turn the unit off, hold the "0" button for 3 seconds.
- This scale comes with an auto-off feature in order to help conserve battery power. The unit will turn off automatically after 5 minutes of being in an idle state.

3

General Weight & Volume Measurement**To ensure accurate measurement:**

- Check the weight of an empty scale every time you first turn on the unit. The display should read 0 (zero). Go to "Calibration" section to calibrate the scale if the reading is other than 0 (zero).
- Be sure that the unit is on a hard, level surface. Do not hold the unit in the air during the weighing process.

Scale Mode:

- When you initially turn on the unit, the display/function will automatically default to "Scale" mode.
- If you are in another mode and want to change to "SCALE" mode, press (M) button repeatedly until the arrow icon is pointing to "SCALE".
- Press (U) to change the unit of measure between pounds-ounces and grams. The unit will default to pounds-ounces.
- Place the ingredient into the cup portion of the scale.
- Ensure that the unit is on a hard, level surface. Do not hold the unit in the air during the weighing process.

Weight unit selection: LBS-OZ and GRAMS

The measurement increments for the "SCALE" mode = 1/8 ounce for pounds-ounces. If finer resolution and higher accuracy is required, please select gram for the measurement as measurement increments for grams = 1 gram.

Flour, Sugar, Water, Milk or Oil Mode:

- Use the (M) button to scroll between the various modes (arrow will indicate which mode you are in).
- Continue pressing the (M) button until you have selected the mode you desire.

4

Weight & Volume Measurement (cont.)

- Press (U) button to change to the desired unit of measure if needed (see below for which units of measure are available for which ingredients/modes).
- Place the ingredient into the cup.
- Be sure that the unit is on a hard, level surface. Do not hold the unit in the air during the weighing process.

NOTE: The volume measurement is converted from the weight & the pre-set density of the ingredient. There are different types of milk, oil, sugar or flour in the market. The density and type of ingredients being used for the scale are shown below. We have also included a handy conversion chart for your use and reference to assist you in converting other foods from weight (FL OZ, mL, LBS-OZ, GRAMS) to volume (CUPS).

Type	Density	Unit of Measure (U) available
Water	1 kg/L	mL, CUPS, FL OZ
Milk*	1.03 kg/L	mL, CUPS, FL OZ
Oil**	0.9 kg/L	mL, CUPS, FL OZ
Sugar †	0.84 kg/L	CUPS, LBS-OZ, GRAMS
Flour ‡	0.6 kg/L	CUPS, LBS-OZ, GRAMS

*Milk = skim or 2% - **Oil = Vegetable, Corn & Olive
 † Sugar = Granulated sugar
 ‡ Flour = All purpose flour – unsifted

The digital measurement increments for CUPS = 1/8 Cup; FL OZ = 1/8 FL OZ; OZ = 1/8 OZ; GRAM = 1 Gram; mL = 1 mL. For items that are lighter or smaller amounts, select gram or mL and convert back to FL OZ/OZ-LBS or CUPS.

5

Weight & Volume Measurement (cont.)**Tare (zero set) Function**

It is easy and convenient to build up and mix different ingredients together all in the same cup. After the first ingredient is added and measured, you may add another ingredient after performing the tare function below.

- Place the cup with first ingredient on hard, even surface.
- Single press "0" button. The reading will reset to zero and the "TARE" icon will remain on the unit display.

Now you can add your additional ingredient. Only the weight or volume of the last ingredient added is reflected in the weight/volume displayed. Continue above procedure to build up different ingredients for your recipe.

If ingredients are removed from the measuring cup after using the Tare function, the display will show a negative number. To reset the scale back to zero for a new measurement, press the "0" button. The display resets to zero.

NOTE: The tare function only operate when the cup is placed on a hard, even surface

Reversing the Tare Function

Right after the tare function has been performed and the display is showing "0" (zero) reading with the "TARE" icon showing, you can press "0" button to resume the original weight or volume reading just before the tare function and the "TARE" icon will disappear.

NOTE: The reverse tare function only operate when the cup is placed on a hard, even surface

6

IMPORTANT NOTE: It is easy and convenient to mix different ingredients in the cup. However when mixing your ingredients, you should avoid pressing down the bottom of the base where the sensitive weight scale components are located. Excessive force applied to the base of the cup may permanently damage the scale.

Error Messages**Unst = Unstable**

The scale is unstable and the unit will turn off automatically. Place the cup on a hard, even flat surface and turn on the unit again by pressing "0" button once.

Err = Error

The scale is overloaded. The weight or volume in the cup exceeds the maximum display range (refer "Specification" section).

Calibration

To be sure accurate measurement, you are suggested to check the weight of an empty cup every time you first turn on the unit. It should read 0 (zero). Calibration for the cup is needed **ONLY** when the reading of your EMPTY cup is other than zero. The calibration process will reset the unit.

To calibrate:

- Ensure the unit is completely empty.
- Turn on the unit by a single press of the "0" button.
- Be sure the unit is placed firmly on a hard, level surface. Hold the "0" button for 6 seconds, during that time the screen will go blank before the "CAL" icon will begin to flash. Release the button. Do not touch or move the cup while "CAL" is flashing.
- The display reading will show "0" (zero) and the calibration is completed.

7

Precautions

- The scale is not dishwasher safe.
- Do not use in microwave ovens.
- Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this unit and may cause damage. The scale contains no user-serviceable parts.
- Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
- This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
- To prevent damage, do not place weighing heavier than the maximum display ranges into the cup.
- Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale.
- Do not store scale on its side.
- This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Remove the battery if the scale will not be used for a long period of time.
- Do not pour solids or liquids into the cup that are greater than 158°F/70°C in temperature. This includes but is not limited to boiling water.
- Do not store/place in refrigerator.

8

Cleaning & Storage

- Clean the inside of the transparent cup with cold or warm water with mild soap. Do not use water more than 158°F/70°C in temperature.
- Use damp cloth to clean the outside of the transparent cup and the handle.
- Never immerse the unit in water or put into dish washer.

Specifications

Maximum temperature:
Does not exceed 158°F / 70°C in temperature

Maximum display range:
3000g, 1420ml, 6 cup, 48 fl oz

Volume resolution:
1/8 cups, 1/8 fl oz, 1 mL

Weight resolution:
1 gram, 1/8 oz

Scale Capacity:
6.6 lbs, 3kg

Battery:
1 x CR2032 Lithium Battery (included)

9

Vegetables

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
PEAS, fresh or frozen		HERBS, basil (leaves)	
1/4 cup (switch to oz)	1 1/2	1/2 cup (switch to oz)	3/4
1/3 cup	2	1 cup	1 1/2
1/2 cup	3	HERBS, parsley (leaves)	
2/3 cup	4	1/2 cup (switch to oz)	3/4
3/4 cup	4 1/2	1 cup	1 1/2
1 cup	6	TOMATO PUREE/SAUCE	
		1/2 cup (switch to fl oz)	1/2
		1/4 cup	2 1/4
		1/3 cup	3 1/4
		1/2 cup	4 1/2
		2/3 cup	6 1/2
		3/4 cup	6 3/4
		1 cup	9

12

Vegetables

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
BROCCOLI, fresh or frozen		CORN KERNELS, fresh or frozen	
1/4 cup (switch to oz)	1 1/4	1/4 cup (switch to oz)	1 1/2
1/3 cup	1 3/4	1/3 cup	2
1/2 cup	2 1/2	1/2 cup	3
2/3 cup	3 1/2	2/3 cup	4
3/4 cup	3 3/4	3/4 cup	4 1/2
1 cup	5	1 cup	6
CARROTS, diced		ONIONS, chopped	
1/4 cup (switch to oz)	1 1/4	1/4 cup (switch to oz)	1/2
1/3 cup	1 3/4	1/3 cup	1 1/4
1/2 cup	2 1/2	1/2 cup	1 1/2
2/3 cup	3 1/2	2/3 cup	2 1/2
3/4 cup	3 3/4	3/4 cup	3 1/4
1 cup	5	1 cup	3 3/4
CELERY, chopped		ONIONS, green, sliced	
1/4 cup (switch to oz)	1 1/4	1/4 cup (switch to oz)	1/4
1/3 cup	1 1/2	1/3 cup	1
1/2 cup	2 1/2	1/2 cup	1 1/4
2/3 cup	3	2/3 cup	2
3/4 cup	3 1/2	3/4 cup	2 1/2
1 cup	4 1/4	1 cup	4

13

Cereal & Grains

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
MACARONI, elbow or small tubes		RICE, long grain white or brown	
1/2 cup (switch to oz)	2	1/4 cup (switch to oz)	1 3/4
1 cup	4	1/3 cup	2 1/4
		1/2 cup	3 1/4
		2/3 cup	4 1/2
		3/4 cup	5
		1 cup	6 1/2
MACARONI, small stars or alphabets		BREAD CRUMBS, plain, dry	
1/2 cup (switch to oz)	2 1/4	1/2 cup (switch to oz)	1 1/2
1 cup	4 1/2	1/3 cup	2
		1/4 cup	2
		1/3 cup	3
		1/2 cup	4
		2/3 cup	4 1/2
		3/4 cup	5 1/2
		1 cup	6
COUSCOUS		OATMEAL	
1/4 cup (switch to oz)	1 1/2	1/4 cup (switch to oz)	1 1/2
1/3 cup	2	1/3 cup	1 1/2
1/2 cup	3	1/2 cup	2
2/3 cup	4	2/3 cup	2 1/4
3/4 cup	4 1/2	1 cup	3
1 cup	6		

14

Liquids

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
WATER		BROTH/STOCK	
1 Tablespoon (switch to fl oz)	1/2	1 Tablespoon (switch to fl oz)	1/2
1/4 cup	2	1/4 cup	2
1/3 cup	3	1/3 cup	3
1/2 cup	4	1/2 cup	4
2/3 cup	5	2/3 cup	5
3/4 cup	6	3/4 cup	6 1/4
1 cup	8	1 cup	8
1 1/2 cups	12	FRUIT JUICE, ORANGE OR LEMON	
2 cups	16 (1 pint)	1 Tablespoon (switch to fl oz)	1/2
		1/4 cup	2 1/4
		1/3 cup	2 3/4
		1/2 cup	4 1/4
		2/3 cup	5 1/2
		3/4 cup	6 1/4
		1 cup	8 1/2
MILK (whole, 2%, 1%), EVAPORATED MILK, BUTTERCREAM, HEAVY CREAM, LIGHT CREAM, HALF AND HALF, SOUR CREAM, PLAIN YOGURT		WINE, BEER, WHISKEY AND OTHER DISTILLED BEVERAGES	
1 Tablespoon (switch to fl oz)	1/2	1 Tablespoon (switch to fl oz)	1/2
1/4 cup	2 1/4	1/4 cup	2
1/3 cup	2 3/4	1/3 cup	3
1/2 cup	4 1/4	1/2 cup	4
2/3 cup	5 1/2	2/3 cup	5
3/4 cup	6 1/4	3/4 cup	6
1 cup	8 1/2	1 cup	8
		1 1/2 cups	12
		2 cups	16 (1 pint)
SWEETENED CONDENSED MILK			
1/4 cup (switch to oz)	1 1/2		
1/2 cup	3		
3/4 cup	4 1/2		
1 cup	6		
COCOA			
1 Tablespoon (switch to oz)	1/4		
1/4 cup	3/4		
1/3 cup	1		
1/2 cup	1 1/2		
2/3 cup	2		
3/4 cup	2 1/2		
1 cup	3 1/4		

15

Nuts

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
ALMONDS, whole		WALNUTS/PECANS, halves	
1/4 cup (switch to oz)	1 1/4	1/4 cup (switch to oz)	1
1/3 cup	1 3/4	1/3 cup	1 1/4
1/2 cup	2 1/2	1/2 cup	2
2/3 cup	3 1/4	2/3 cup	2 1/4
3/4 cup	3 3/4	3/4 cup	2 1/2
1 cup	5	1 cup	3 1/2
ALMONDS, slivered		WALNUTS/PECANS, coarsely chopped	
1/4 cup (switch to oz)	1	1/4 cup (switch to oz)	1
1/3 cup	1 1/2	1/3 cup	1 1/4
1/2 cup	2	1/2 cup	2
2/3 cup	2 3/4	2/3 cup	2 1/2
3/4 cup	3	3/4 cup	3
1 cup	4	1 cup	4
ALMONDS, sliced		PEANUT BUTTER	
1/4 cup (switch to oz)	3/4	1 Tablespoon (switch to oz)	3/4
1/3 cup	1	1/4 cup	2 1/2
1/2 cup	1 1/2	1/3 cup	3 1/4
2/3 cup	2	1/2 cup	5
3/4 cup	2 1/4	2/3 cup	6 1/2
1 cup	3	3/4 cup	7 1/2
		1 cup	10

16

Miscellaneous

Standard U.S. Measure	Equivalent Measure in Weight	Standard U.S. Measure	Equivalent Measure in Weight
DRY, GRANULATED YEAST		RAISINS	
2 1/4 teaspoons	1/4		